


TE590

Quick Start Guide



Thanks for choosing our product!










This Quick Start Guide Only applicable to: TE590.

Before using the product, please read the Quick Start Guide to fully benefit from it.

Note

- Warranty period is 1 year from date of purchase.
- This product involves constant upgrading and/or improvement, our company reserves the right to change the specifications of software and/or hardware mentioned in this operating guide without any prior notice. The product specifications and information mentioned in the operating guide are for reference only.

Check List


 TE590×1	 Battery×1	 Belt Clip×1
 Travel Charger×1	 USB-C Cable×1	 Desktop Charger×1
 Screwdriver×1	 Quick Start Guide×1	 Warranty Card×1

Notice:

Please check the following accessories before you discard the packing material. Please contact your local dealer immediately if there is any missing or damage parts.

Before Use

1. Screw the screw anticlockwise and take down the SIM cover, then insert the SIM/TF card



2. Put back the cover, tighten the screw clockwise. Put back and push to lock the battery.



3. Press and hold the power button until the screen lights up (about 3 seconds). Press the power button to put the terminal to sleep, press again to wake it up.



4.Pull the “Battery Lock” if there be a need to uninstall the battery.


Charging

● Using USB-C Cable




● Using Desktop Charger

Led Indicator	Battery Status
Red(Steady)	Recharging
Green(Steady)	Charged full




Battery charging indicator

Indication
Red(Steady)
Red(Blinking)
Red(Steady)
Green(Steady)



Operating State
USB Charging
Low Battery
PTT Transmitting
PTT Receiving



Caution

- Only use the provided devices to charge the terminal.
- Do not function the device when charging.
- Do not use the above two charging methods simultaneously.

Cautions

1. Avoid any physic damage to the terminal.
2. Do not store the device under any circumstance contain electronic erosive material.
3. Avoid to pull the device up by holding the antenna or accessories.
4. Please power off and unload the battery before cleaning the terminal.
5. Using dry and clean lint free cloth or hairbrush to keep the terminal and the golden charging pin clean.
6. To avoid of any damage, do not use any chemical agent including detergent, alcohol, aerosol spray or oil preparations as cleaning solution.
7. Please make sure to keep the terminal clean and dry after cleaning and before using.



Tooo Air Pty. Ltd.

Suite 1103, 1 Newland St

Bondi Junction, NSW 2022

Phone:

+61 2 9157 0540

Web:

www.toooair.com.au

Email:

info@toooair.com.au